



# INSTALLATION GUIDE

## SPRINTER MURPHY BED

SP0314B



### TOOLS REQUIRED (NOT INCLUDED)

- |                           |                           |
|---------------------------|---------------------------|
| + 5MM WRENCH              | + 13MM WRENCH             |
| + 7/32" ALLEN WRENCH      | + 19MM WRENCH             |
| + 3/16" ALLEN WRENCH      | + RIVET NUT TOOL          |
| + 3/4" WRENCH OR SOCKET   | + 25/64" DRILL BIT        |
| + 9/16" WRENCH OR SOCKET  | + 5/16" DRILL BIT         |
| + 7/16" WRENCH OR SOCKET  | + POWER DRILL             |
| + 3/8" WRENCH OR SOCKET   | + MEASURING TAPE          |
| + 11/32" WRENCH OR SOCKET | + SAW                     |
| + 12MM WRENCH             | + RUST PREVENTATIVE PAINT |

### INSTALL INFO

TIME TO INSTALL THIS PRODUCT: 3-5 HOURS

Additional help is suggested for a few of the install steps.

### BEFORE YOU START

Please inspect the product and packaging upon delivery to ensure there are no issues and that all parts and hardware are accounted for.

Contact us ASAP if anything is missing at:  
[support@flatlinevanco.com](mailto:support@flatlinevanco.com)


# BEFORE YOU START

All Flatline Van Co products must be properly assembled and secured before attaching to your vehicle. Improper attachment could result in an automobile accident, and could cause serious bodily injury or death to you or to others involved. You are responsible for assembling and securing Flatline Van Co products to your vehicle, checking the mounting points and attachments prior to use, and regularly inspecting the products for wear and or damage. We always recommend you use a professional to install any aftermarket accessories to your vehicle. If you have no mechanical experience and are not thoroughly familiar with the installation procedures, you must have the product installed by a professional installer or other qualified persons. The responsibility is yours and must be taken seriously for everyone's safety.




**[SP0314B.1]**

# TABLE CABINET SIDE PANELS



RIGHT SIDE CABINET END

QTY: 1




LEFT SIDE CABINET END

QTY: 1


# [SPO314B.2]

# TABLE CABINET STRETCHERS




LANDING FLANGE

QTY: 1




TOE KICK

QTY: 1




WALL MOUNTING BRACKETS

QTY: 2




1/4-20 X 1 FLANGED  
HEX HEAD SCREW

QTY: 2




1/4-20 X 0.75 SQUARE  
NECK CARRIAGE BOLT

QTY: 8



1/4-20 NYLON INSERT  
LOCKNUT

QTY: 8



3/8-16 NYLON INSERT  
LOCKNUT

QTY: 2



1/4-20 X 0.027-0.165 THK HEAVY  
DUTY RIVET NUT

QTY: 2




1/4 SCREW FLAT WASHER

QTY: 10



3/8 SCREW FLAT WASHER

QTY: 2




3/8-16 X 0.75 BUTTON  
HEAD HEX DRIVE SCREW

QTY: 2

# [SPO314B.3]

## SHELVES AND SIDE PANELS




CABINET SHELF

QTY: 2




SHELF COVER PLATE

QTY: 2




1/4-20 X 0.75 SQUARE NECK  
CARRIAGE BOLT

QTY: 8




1/4-20 NYLON INSERT  
LOCKNUT

QTY: 8



1/4 SCREW FLAT WASHER

QTY: 8




1/4-20 X 0.75 FLANGED  
BUTTON HEAD HEX DRIVE  
SCREW

QTY: 8


# [SP0314B.4]

# UTILITY ACCESS PANELS




UTILITY ACCESS PANELS

QTY: 2




1/4-20 X 0.75 SQUARE NECK  
CARRIAGE BOLT

QTY: 12



1/4-20 NYLON INSERT  
LOCKNUT

QTY: 12




1/4 SCREW FLAT WASHER

QTY: 12


# [SP0314B.5]

## SLIDING DOOR FRAMES




LARGE SLIDING DOOR CUBBY

QTY: 1




SMALL SLIDING DOOR CUBBY

QTY: 1




1/4-20 X 0.75 SQUARE NECK  
CARRIAGE BOLT

QTY: 12




1/4-20 NYLON INSERT  
LOCKNUT

QTY: 12




1/4 SCREW FLAT WASHER

QTY: 12




3/8-16 X 1.25 HEX DRIVE FLAT  
HEAD SCREW

QTY: 11




1/4-20 X 0.75 SQUARE  
NECK CARRIAGE BOLT

QTY: 3




M8-1.25 NYLON INSERT  
LOCKNUT

QTY: 4




1/4-20 NYLON INSERT  
LOCKNUT

QTY: 3




3/8-16 NYLON INSERT LOCKNUT

QTY: 15




3/8 UHMW PLASTIC  
WASHER

QTY: 4




1/4 SCREW FLAT WASHER

QTY: 3




3/8 SCREW FLAT WASHER

QTY: 15



3/8-16 X 1 BUTTON HEAD HEX  
DRIVE SCREW

QTY: 4




M8 FLAT WASHER

QTY: 4




# [SP0314B.6b]

## CHEST TABLE ASSEMBLY




CENTER BRACKET

QTY: 1




CHEST GAS STRUT

QTY: 2




RIGHT CHEST STRUT BRACKET 1

QTY: 1




LEFT CHEST STRUT BRACKET 1

QTY: 1




RIGHT CHEST STRUT BRACKET 2

QTY: 1




LEFT CHEST STRUT BRACKET 2

QTY: 1




LEFT TABLE SUPPORT

QTY: 1



RIGHT TABLE SUPPORT


QTY: 1



TOP TRAY


QTY: 1

# [SP0314B.7] HINGE CABINET SIDE PANELS



RIGHT SIDE CABINET END


QTY: 1



LEFT SIDE CABINET END


QTY: 1

# [SP0314B.8a] HINGE CABINET STRETCHERS




FRONT SUPPORT

QTY: 1




TOE KICK

QTY: 1




BACK SUPPORT

QTY: 1




RH HINGE PLATE

QTY: 1




LH HINGE PLATE

QTY: 1



BED STRUT BRACKET


QTY: 2



WALL MOUNTING BRACKETS


QTY: 2

# [SP0314B.8b] HINGE CABINET STRETCHERS




1/4-20 X 1 FLANGED  
HEX HEAD SCREW

QTY: 2




1/4-20 X 0.75 SQUARE  
NECK CARriage BOLT

QTY: 12



1/4-20 NYLON INSERT  
LOCKNUT

QTY: 16



3/8-16 NYLON INSERT  
LOCKNUT

QTY: 6



1/4-20 X 0.027-0.165 THK HEAVY  
DUTY RIVET NUT

QTY: 2




1/4 SCREW FLAT WASHER

QTY: 18




3/8 SCREW FLAT WASHER

QTY: 6



1/4-20 X 0.75 FLANGED  
BUTTON HEAD HEX DRIVE  
SCREW

QTY: 14




3/8-16x1.5 HEX DRIVE  
BUTTON HEAD SCREW

QTY: 6


# [SP0314B.9]

## DRAWER COMPONENTS




**DRAWER CATCH**

**QTY: 1**




**DRAWER SLIDE PLATE**

**QTY: 2**



**DRAWER**

**QTY: 1**




**1/4-20 X 0.75 SQUARE NECK  
CARRIAGE BOLT**

**QTY: 9**



**1/4 SCREW FLAT WASHER**

**QTY: 9**




**1/4-20 NYLON INSERT LOCKNUT**

**QTY: 9**



**8-32 NYLON INSERT LOCKNUT**

**QTY: 6**



**8-32 X .5" BUTTON HEAD HEX  
DRIVE SCREW**

**QTY: 6**




**#8 WASHER**

**QTY: 6**


# [SP0314B.10]

## BED FRAME ASSEMBLY




**BED FRAME**

**QTY: 1**




**BED GAS STRUT**

**QTY: 2**




**HINGE PIN WIRE LOCK**

**QTY: 1**




**PIVOT BUSHINGS**

**QTY: 4**



**3/8-16 X 1.75 FLANGED HEX HEAD  
SCREW**

**QTY: 10**



**1/2 OVERSIZED FLAT WASHER**

**QTY: 2**




**3/8 OVERSIZED FLAT WASHER**

**QTY: 10**




**MOUNTING WASHER**

**QTY: 10**




**0.5-13 NYLON INSERT LOCKNUT**

**QTY: 2**




**0.5-13 X 1.75 HEX HEAD SCREW**

**QTY: 2**



**M8 X 1.25mm CAP NUT**

**QTY: 2**




**3/8-16 NYLON INSERT LOCKNUT**

**QTY: 10**


# [SP0314B.11]

## OVERHEAD SHELF




OVERHEAD SHELF

QTY: 1




M12X1.75MM HEX NUT

QTY: 2




M12 WASHER

QTY: 2




1/4-20 X 0.027-0.165 THK HEAVY  
DUTY RIVET NUT

QTY: 5



1/4-20 X 1 FLANGED BUTTON HEAD  
HEX DRIVE SCREW

QTY: 5



1/4 SCREW FLAT WASHER

QTY: 5




12MM BALL STUD

QTY: 1


# [SP0314B.12]

## END CAP COVERS




TALL END CAP

QTY: 2




END CAP WALL BRACKET

QTY: 6




END COVER PLATE

QTY: 4




1/4-20 X 0.75 SQUARE NECK  
CARRIAGE BOLT

QTY: 6




1/4-20 NYLON INSERT LOCKNUT

QTY: 16



1/4 SCREW FLAT WASHER

QTY: 16




1/4-20 X 0.75 FLANGED  
BUTTON HEAD HEX DRIVE  
SCREW

QTY: 34



[SP0314B.13]

# HINGE CABINET TOP




BAMBOO CABINET TOP

QTY: 1


# [SP0314B.14]

## FLARE WINGS




WING FLARE

QTY: 2




WING FLARE SUPPORT BRACKET

QTY: 4




1/4-20 X 0.75 SQUARE NECK  
CARRIAGE BOLT

QTY: 4




1/4-20 NYLON INSERT LOCKNUT

QTY: 8



1/4 SCREW FLAT WASHER

QTY: 8




1/4-20 X 1 FLANGED BUTTON  
HEAD HEX DRIVE SCREW

QTY: 4


[SP0314B.15]

# SLIDING DOORS



LARGE SLIDING DOORS

QTY: 2




SMALL SLIDING DOORS

QTY: 2

[SP0314B.16]

# FOLDING TABLE TOP




FOLDING TABLE TOP

QTY: 1


[SP0314B.17]

# MOLLE PANELS




BED SIDE MOLLE PANEL

QTY: 2




1/4-20 X 0.5 FLANGED BUTTON  
HEAD HEX DRIVE SCREWS

QTY: 12



1/4-20 X 0.49 BINDING  
BARREL

QTY: 12



PANEL STANDOFF

QTY: 12

# INSTALL

## STEP | 01 LAYOUT AND INSTALL PREP

**1.1 Inspect Murphy Bed Crate:** The FVC Sprinter Murphy Bed System is shipped in a **Crate** comprising of **17 Boxes** inside. See **FIG 1** for box designations and the way you'll find them stacked inside. We recommend leaving everything boxed up until directed to open them in each of the following steps.

**SP0314B.1** - Table Cabinet Side Panels

**SP0314B.2** - Table Cabinet Stretcher/Toe Kick

**SP0314B.3** - Cabinet Shelves and Side Panels

**SP0314B.4** - Utility Access Panels

**SP0314B.5** - Sliding Door Frames

**SP0314B.6** - Chest Table Assembly

**SP0314B.7** - Hinge Cabinet Side Panels

**SP0314B.8** - Hinge Cabinet Stretcher/Toe Kick

**SP0314B.9** - Drawer

**SP0314B.10** - Bed Frame Assembly

**SP0314B.11** - Overhead Shelf

**SP0314B.12** - End Cap Covers

**SP0314B.13** - Hinge Cabinet Top



**SP0314B.14** - Flare Wings

**SP0314B.15** - Sliding Doors

**SP0314B.16** - Folding Table Top

**SP0314B.17** - Molle Panels

**[SIDE VIEW OF CRATE] ----->**



**FIG 1**

**PARTS NEEDED:** + RH TABLE CABINET END (SP0314B.1)  
 + LH TABLE CABINET END (SP0314B.1)  
 + LANDING FLANGE (SP0314B.2)

**TOOLS REQUIRED FOR THIS STEP:** + 7/32" ALLEN WRENCH  
 + 9/16" WRENCH OR SOCKET

## STEP | 02 TABLE SIDE ASSEMBLY

**2.1 Assemble Cabinet Ends and Flange:** Attach Left-Hand and Right-Hand Cab Ends to Landing Flange using (2) 3/8-16 x 0.75 Button Head Screws, Flat Washer and Nylon Locknuts.




FIG 2




FIG 3




FIG 4

**PARTS NEEDED:** + TOE KICK (SP0314B.2)

**TOOLS REQUIRED FOR THIS STEP:** + 7/16" WRENCH OR SOCKET

## STEP | 02 TABLE SIDE ASSEMBLY

**2.2 Assemble Cabinet Ends and Toe Kick:** Attach Toe Kick to Left-Hand and Right-Hand Cab Ends using (4) 1/4-20 x 0.75 Square Neck Carriage Bolts, Flat Washers and Nylon Locknuts.




FIG 5



FIG 6



FIG 7



**PARTS NEEDED:** + TOP TRAY (SP0314B.6)  
 + RH CHEST STRUT BRACKET (SP0314B.6)  
 + LH CHEST STRUT BRACKET (SP0314B.6)

**TOOLS REQUIRED FOR THIS STEP:** + 7/32" ALLEN WRENCH  
 + 9/16" WRENCH OR SOCKET

## STEP | 02 TABLE SIDE ASSEMBLY

**2.3 Attach Top Tray and Strut Brackets:** Attach Top Tray and Strut Brackets to Left-Hand and Right-Hand Cab Ends using (4) 3/8-16 x 0.75 Button Head Screws, Flat Washers and Nylon Locknuts.

**NOTE -** The Strut Brackets are *directional*. See **FIG 9** for *right-side* and **FIG 10** for *left-side* orientation.




FIG 8

### OUTSIDE VIEW




FIG 9

### INSIDE VIEW




FIG 10

**PARTS NEEDED:**

**TOOLS REQUIRED FOR THIS STEP:** + 7/16" WRENCH OR SOCKET

## STEP | 02 TABLE SIDE ASSEMBLY

**2.4 Attach Top Tray to Landing Flange:** Fasten Top Tray to Landing Flange using (2) 1/4-20 x 0.75 Square Neck Carriage Bolts, Flat Washers and Nylon Locknuts.




FIG 11



FIG 12




FIG 13

**PARTS NEEDED:** + CHEST GAS STRUTS (SP0314B.6)

**TOOLS REQUIRED FOR THIS STEP:** + 12MM WRENCH  
+ 13MM WRENCH

## STEP | 02 TABLE SIDE ASSEMBLY

**2.5 Attach Gas Struts to Brackets:** Fasten **Gas Struts** to the **Left and Right Side Chest Strut Brackets** in the orientation shown in **FIG 14** using **(2) M8 Nylon Locknuts and Flat Washers (FIG 15)**.




FIG 14




FIG 15

**PARTS NEEDED:** + RH CHEST STRUT BRACKET 2 (SP0314B.6)  
 + LH CHEST STRUT BRACKET 2 (SP0314B.6)  
 + LEFT TABLE SUPPORT (SP0314B.6)  
 + RIGHT TABLE SUPPORT (SP0314B.6)  
 + FOLDING TABLE TOP (SP0314B.16)

**TOOLS REQUIRED FOR THIS STEP:** + 7/32" ALLEN WRENCH  
 + 9/16" WRENCH OR SOCKET

## STEP | 02 TABLE SIDE ASSEMBLY

**2.6 Attach Strut and Support Brackets to Table Top:** Fasten Left and Right Strut Brackets and Left and Right Support Brackets to Folding Table Top using (2ea) 3/8-16 x 1.25 Hex Drive Flat Head Screws, 3/8" Plastic Washers, Flat Washers and Nylon Locknuts [in that order, FIG 17].

**NOTE -** Tighten the hardware for the **Support Brackets** to the point that they are able to **swing in and out** with only **slight resistance**.




FIG 16




FIG 17

## PARTS NEEDED:

TOOLS REQUIRED FOR THIS STEP: + 7/32" ALLEN WRENCH  
+ 9/16" WRENCH OR SOCKET

### STEP | 02 TABLE SIDE ASSEMBLY

**2.7 Attach Table Top to Top Tray:** Attach the **Table Top** to the **Top Tray** using (3) 3/8-16 x 1.25 Hex Drive Flat Head Screws, Flat Washers and Nylon Locknuts in the locations shown in FIG 18.




FIG 18

#### OUTSIDE VIEW




FIG 19

#### INSIDE VIEW






FIG 20

## PARTS NEEDED:

TOOLS REQUIRED FOR THIS STEP: + 12MM WRENCH  
+ 13MM WRENCH

### STEP | 02 TABLE SIDE ASSEMBLY

**2.8 Attach Table Top to Gas Struts:** Attach the **Table Top** to the **Gas Struts** inside the **Top Tray** using **(1ea) M8 Flat Washers** and **Nylon Locknuts** in the locations shown in **FIG 21+22**.



## PARTS NEEDED:

## TOOLS REQUIRED FOR THIS STEP:

### STEP | 02 TABLE SIDE ASSEMBLY

**2.9 Choose Table Side Configuration:** You may choose to have the **Utility Access Panels** or the **Sliding Doors** on *either* the **top** or the **bottom** of your **Middle Tray**, depending on your needs. See **FIG 23 and 24** for visuals of both options. For best results, we'll be starting with the bottom set of doors.



FIG 23



FIG 24



**PARTS NEEDED:** + UTILITY ACCESS PANELS (SP0314B.4)  
OR  
+ LARGE SLIDING DOOR CUBBY (SP0314B.5)

**TOOLS REQUIRED FOR THIS STEP:** + 7/16" WRENCH OR SOCKET

## STEP | 02 TABLE SIDE ASSEMBLY

**2.10 Install Bottom Doors:** The mounting holes and hardware for the **Large Sliding Door Cubby** and **Utility Access Panels** are the same. Attach your selection of **Bottom Doors** to the **Left and Right Cabinet Ends** using (4) 1/4-20 x 0.75 Square Neck Carriage Bolts, Flat Washers and Nylon Locknuts (FIG 25). There's a final mounting location in the middle of the unit that will take (1) 1/4-20 x 0.75 Square Neck Carriage Bolt, Flat Washer and Nylon Locknut to finish out this step (FIG 26).




FIG 25




FIG 26



**PARTS NEEDED:** + CABINET SHELF ASSEMBLY (SP0314B.3)

**TOOLS REQUIRED FOR THIS STEP:** + 7/16" WRENCH OR SOCKET

## STEP | 02 TABLE SIDE ASSEMBLY

**2.11 Install Cabinet Shelf Assembly:** Attach the **Cabinet Shelf Assembly** to the **Left and Right Cabinet Ends** using **(4) 1/4-20 x 0.75 Square Neck Carriage Bolts, Flat Washers and Nylon Locknuts (FIG 27)**. There's a final mounting location in the middle of the unit that will take **(1) 1/4-20 x 0.75 Square Neck Carriage Bolt, Flat Washer and Nylon Locknut** to finish out this step **(FIG 28)**.




FIG 27




FIG 28

**PARTS NEEDED:** + SHELF SIDE PLATES (SP0314B.3)

**TOOLS REQUIRED FOR THIS STEP:** + 3/16" ALLEN WRENCH

## STEP | 02 TABLE SIDE ASSEMBLY

**2.12 Install Shelf Side Plates:** Attach the **Shelf Side Plates** to the pre-threaded holes of the **Cabinet Shelf Assembly** using (2ea) 1/4-20 x 0.75 Flanged Button Head Screws (FIG 30).




FIG 29




FIG 30

**PARTS NEEDED:** + CENTER SUPPORT BRACKET (SP0314B.6)

**TOOLS REQUIRED FOR THIS STEP:** + 7/16" WRENCH OR SOCKET

## STEP | 02 TABLE SIDE ASSEMBLY

**2.13 Install Center Bracket:** Attach the Center Support Bracket to the middle of the Landing Flange using (1) 1/4-20 x 0.75 Square Neck Carriage Bolts, Flat Washers and Nylon Locknuts (FIG 32).




FIG 31




FIG 32

**PARTS NEEDED:** + UTILITY ACCESS PANELS (SP0314B.4)  
OR  
+ LARGE SLIDING DOOR CUBBY (SP0314B.5)

**TOOLS REQUIRED FOR THIS STEP:** + 7/16" WRENCH OR SOCKET

## STEP | 02 TABLE SIDE ASSEMBLY

**2.14 Install Upper Doors:** The mounting holes and hardware for the **Sliding Doors** and **Utility Access Panels** are the same. Attach your selection of **Upper Doors** to the **Left and Right Cabinet Ends** using (4) 1/4-20 x 0.75 Square Neck Carriage Bolts, Flat Washers and Nylon Locknuts (FIG 33). Finish by attaching it to the **Center Bracket** (1) 1/4-20 x 0.75 Square Neck Carriage Bolt, Flat Washer and Nylon Locknut to finish out this step (FIG 34).



FIG 33




FIG 34

**PARTS NEEDED:** + RH HINGE CABINET END (SP0314B.7)  
 + LH HINGE CABINET END (SP0314B.7)  
 + FRONT SUPPORT (SP0314B.8)  
 + RH HINGE PLATE (SP0314B.8)  
 + LH HINGE PLATE (SP0314B.8)

**TOOLS REQUIRED FOR THIS STEP:** + 9/16" WRENCH OR SOCKET  
 + 7/32" ALLEN WRENCH

## STEP | 03 HINGE SIDE ASSEMBLY

**3.1 Attach Left and Right Side Cabinet Ends to Front Support:**  
 Sandwich the **Left and Right Hinge Plates** between the **Left and Right Side Cabinet Ends** and the **Front Support** and fasten together using (3ea) 3/8-16 x 1.5 Button Head Screws, Flat Washers and Nylon Locknuts (FIG 36).

**NOTE -** Notice that the **Hinge Plates** are **directional**. See FIG 35 for the orientation of the left and right side plates.




FIG 35




FIG 36

**PARTS NEEDED:** + BACK SUPPORT (SP0314B.8)

**TOOLS REQUIRED FOR THIS STEP:** + 7/16" WRENCH OR SOCKET

## STEP | 03 HINGE SIDE ASSEMBLY

**3.2 Attach Left and Right Side Cabinet Ends to Back Support:**  
Attach the **Left and Right Side Cabinet Ends** to the **Back Support** using **(4) 1/4-20 Square Neck Carriage Bolts, Flat Washers and Nylon Locknuts** (FIG 38).




FIG 37




FIG 38

**PARTS NEEDED:** + BED STRUT BRACKET (SP0314B.8)

**TOOLS REQUIRED FOR THIS STEP:** + 7/16" WRENCH OR SOCKET

## STEP | 03 HINGE SIDE ASSEMBLY

**3.3 Attach Bed Strut Brackets Left and Right Side Cabinet Ends:** Attach the Left and Right Side Cabinet Ends to the Front Support using (2ea) 1/4-20 Flanged Button Head Screws, Flat Washers and Nylon Locknuts (FIG 40).

**NOTE -** Make sure that the flange of the **Strut Brackets** are pointed toward the center of the bed.



FIG 39




FIG 40



**PARTS NEEDED:** + TOE KICK (SP0314B.8)

**TOOLS REQUIRED FOR THIS STEP:** + 7/16" WRENCH OR SOCKET

## STEP | 03 HINGE SIDE ASSEMBLY

**3.4 Attach Toe Kick to Left and Right Side Cabinet Ends:** Attach the **Left and Right Side Cabinet Ends** to the **Front Support** using **(4) 1/4-20 Square Neck Carriage Bolts, Flat Washers and Nylon Locknuts (FIG 42)**.



FIG 41




FIG 42



PARTS NEEDED:

TOOLS REQUIRED FOR THIS STEP:

## STEP | 03 HINGE SIDE ASSEMBLY

**3.5 Determine Hinge Side Configuration:** You may choose to have the **Utility Access Panels** or the **Sliding Doors** on *either* the **top** or the **bottom** of your **Cabinet Shelf**, depending on your needs. See **FIG 43 and 44** for visuals of both options. For best results, we'll be starting with the bottom set of doors.



FIG 43




FIG 44

**PARTS NEEDED:** + UTILITY ACCESS PANELS (SP0314B.4)  
OR  
+ SMALL SLIDING DOOR CUBBY (SP0314B.5)

**TOOLS REQUIRED FOR THIS STEP:** + 7/16" WRENCH OR SOCKET

## STEP | 03 HINGE SIDE ASSEMBLY

**3.6 Attach Lower Doors to Left and Right Side Cabinet Ends:** Attach your selection of **Lower Doors** to the **Left and Right Side Cabinet Ends** using (4) 1/4-20 Square Neck Carriage Bolts, Flat Washers and Nylon Locknuts (FIG 46). There's a final mounting location in the middle of the unit that will take (1) 1/4-20 x 0.75 Square Neck Carriage Bolt, Flat Washer and Nylon Locknut to finish out this step (FIG 46).

**NOTE** - If you would prefer the *Small Sliding Doors* at the bottom, notice the additional mounting holes to accommodate the *Cubby Frame* and *Cabinet Shelf*. Simply use those instead.




FIG 45




FIG 46

**PARTS NEEDED:** + CABINET SHELF ASSEMBLY (SP0314B.3)

**TOOLS REQUIRED FOR THIS STEP:** + 7/16" WRENCH OR SOCKET

## STEP | 03 HINGE SIDE ASSEMBLY

**3.7 Install Cabinet Shelf:** Attach the **Cabinet Shelf** to the **Left and Right Cabinet Ends** using **(4) 1/4-20 x 0.75 Square Neck Carriage Bolts, Flat Washers and Nylon Locknuts**. There's a final mounting location in the middle of the unit that will take **(1) 1/4-20 x 0.75 Square Neck Carriage Bolt, Flat Washer and Nylon Locknut** to finish out this step (FIG 48).




FIG 47




FIG 48

**PARTS NEEDED:** + UTILITY ACCESS PANELS (SP0314B.4)  
OR  
+ SMALL SLIDING DOOR CUBBY (SP0314B.5)

**TOOLS REQUIRED FOR THIS STEP:** + 7/16" WRENCH OR SOCKET

## STEP | 03 HINGE SIDE ASSEMBLY

**3.8 Attach Upper Doors to Left and Right Side Cabinet Ends:**  
Attach your selection of **Lower Doors** to the **Left and Right Side Cabinet Ends** using **(4) 1/4-20 Square Neck Carriage Bolts, Flat Washers and Nylon Locknuts (FIG 50)**.



FIG 49




FIG 50

**PARTS NEEDED:** + SHELF SIDE PLATE (SP0314B.3)

**TOOLS REQUIRED FOR THIS STEP:** + 3/16" ALLEN WRENCH

## STEP | 03 HINGE SIDE ASSEMBLY

**3.9 Attach Shelf Covers to Middle Tray:** Attach the **Shelf Cover Plates** to the pre-threaded locations of the **Middle Tray** using (2ea) 1/4-20 x 0.75 Flanged Button Head Screws (FIG 52).




FIG 51




FIG 52

**PARTS NEEDED:** + DRAWER SLIDE PLATE (SP0314B.9)

**TOOLS REQUIRED FOR THIS STEP:** + 7/16" WRENCH OR SOCKET

## STEP | 03 HINGE SIDE ASSEMBLY

**3.10 Attach Drawer Cover Plates to Left and Right Cabinet Ends:** Attach the **Drawer Cover Plates** to the **Left and Right Side Cabinet Ends** using (4ea) 1/4-20 x 0.75 Square Neck Carriage Bolts, Flat Washers and Nylon Locknuts (FIG 54).

**NOTE** - Notice that the **Drawer Cover Plates** have **arrows** cutout to indicate the direction in which they should be installed.



FIG 53




FIG 54



**PARTS NEEDED:** + DRAWER ASSEMBLY (SP0314B.9)

**TOOLS REQUIRED FOR THIS STEP:** + 11/32" WRENCH OR SOCKET  
+ 3/32" ALLEN WRENCH

## STEP | 03 HINGE SIDE ASSEMBLY

**3.11 Attach Drawer Assembly to Drawer Cover Plates:** Slide out the **Drawer Slides** to expose the mounting holes that will be used to attach the **Drawer Assembly** to the **Drawer Cover Plates**. Support the **Drawer Assembly** with help or a table of appropriate height and secure using (3ea) 8-32 x 0.5 Button Head Screws, Flat Washers and Nylon Locknuts (FIG 56).




FIG 55




FIG 56

**PARTS NEEDED:** + DRAWER CATCH (SP0314B.9)

**TOOLS REQUIRED FOR THIS STEP:** + 7/16" WRENCH OR SOCKET

## STEP | 03 HINGE SIDE ASSEMBLY

**3.12 Attach Drawer Catch to Front Support:** Slide out the **Drawer** to expose the mounting hole that will be used to attach the **Drawer Catch** to the **Front Support**. Secure in the orientation shown using **(1) 1/4-20 0.75 Square Neck Carriage Bolt, Flat Washer and Nylon Locknut (FIG 58)**.




FIG 57




FIG 58



**PARTS NEEDED:** + OVERHEAD SHELF (SP0314B.11)  
+ 12MM GOVI BALL STUD (SP0314B.11)  
+ M12 NUTS AND WASHERS (SP0314B.11)

**TOOLS REQUIRED FOR THIS STEP:** + 19MM WRENCH

## STEP | 04 INSTALL SHELF TO VAN

**4.1 Assemble Overhead Shelf:** Loosely install 12mm Ball Stud to the Overhead Shelf in the location shown using (2) M12 Nuts and Flat Washers (FIG 60).




FIG 59




FIG 60

**PARTS NEEDED:** + OVERHEAD SHELF ASSEMBLY (LAST STEP)

**TOOLS REQUIRED FOR THIS STEP:** + POWER DRILL  
+ 25/64" DRILL BIT  
+ RIVET NUT TOOL  
+ 3/16" ALLEN WRENCH

## STEP | 04 INSTALL MURPHY TO VAN

**4.2 Install Overhead Shelf:** Determine the mounting location for your **Overhead Shelf** and mark your holes for mounting through the slots in the top and bottom edges of the shelf. It can be on *either* the **Passenger** or **Driver Side**, but should be as *far back* as it can be to the *rear of the van*, with just enough room to attach the **End Caps** and **Molle Panels**, if applicable (about 3/4" inch). See FIG 61.

We include enough **1/4-20 Rivet Nuts, Flanged Button Head Screws and Flat Washers** for *three sets of hardware* on the **top side** and *two* on the **bottom edge**. See FIG 62 for an example of how you might secure the shelf to your van.

Drill out the holes using a 25/64" bit and install **Rivet Nuts** using a **Rivet Nut Tool**.

Secure **Overhead Shelf** to the van using **1/4-20 x 1 Flanged Button Head Screws and Flat Washers**.



FIG 61




FIG 62

**PARTS NEEDED:** + TALL END CAPS (SP0314B.12)

**TOOLS REQUIRED FOR THIS STEP:** + 7/16" WRENCH OR SOCKET

## STEP | 05 FIT CABINETS TO VAN

**5.1 Attach Hinge Side Cabinet to Overhead Shelf and Cabinet:**  
Place the **Hinge Side Cabinet** beneath the **Overhead Shelf** in your van and attach the **Left and Right Side End Caps** to the **Overhead Shelf** using (3ea) 1/4 x 0.75 Square Neck Carriage Bolts, Flat Washers and Nylon Locknuts (FIG 63). Secure to the **Hinge Cabinet** using (2ea) 1/4-20 x 0.75 Flanged Button Head Screws, Flat Washers and Nylon Locknuts (FIG 64).

**NOTE** - If your **Murphy Bed** is installed in a **170" Wheelbase Sprinter**, you'll need to remove one **Wheel Well Cover** from each cabinet. To do this, remove the (4) 1/4-20 x 0.75" **Flanged Button Head Screws, Flat Washers and Locknuts** along the front and (1) 1/4-20 x 0.75" **Carriage Bolt with Flat Washer and Nylon Locknut** on the side securing the **Cover** to the **Cabinet End** (FIG 65). The specific side depends on whether the **Hinge/Table Cabinets** are installed on the **driver or passenger side**.




FIG 63




FIG 64




FIG 65

## PARTS NEEDED:

TOOLS REQUIRED FOR THIS STEP: + 7/16" WRENCH OR SOCKET

### STEP | 05 FIT CABINETS TO VAN

**5.2 Place Table Side Cabinet:** Place the **Table Side Cabinet** across from the **Hinge Side Cabinet**.

**NOTE** - If your **Murphy Bed** is installed in a **170" Wheelbase Sprinter**, you'll need to remove one **Wheel Well Cover** from each cabinet. To do this, remove the **(4) 1/4-20 x 0.75" Flanged Button Head Screws, Flat Washers and Locknuts** along the front and **(1) 1/4-20 x 0.75" Carriage Bolt with Flat Washer and Nylon Locknut** on the side securing the **Cover** to the **Cabinet End (FIG 67)**. The specific side depends on whether the **Hinge/Table Cabinets** are installed on the **driver** or **passenger side**.



FIG 66




FIG 67



**PARTS NEEDED:** + WING FLARE (SP0314B.14)

**TOOLS REQUIRED FOR THIS STEP:** + MEASURING TAPE  
+ PENCIL  
+ SAW

## STEP | 05 FIT CABINETS TO VAN

**5.3 Measure and Trim Wing Flares:** Mock up the **Wing Flares** to the **Flares** of your van, if applicable, and cut them to suit your available space.

**NOTE** - *Be very careful and trim only as much as you'll need to.*



FIG 68



FIG 69

**PARTS NEEDED:** + WING FLARE (LAST STEP)  
+ WING FLARE SUPPORT BRACKETS (SP0314B.14)

**TOOLS REQUIRED FOR THIS STEP:** + 3/16" ALLEN WRENCH  
+ 7/16" WRENCH OR SOCKET

## STEP | 05 FIT CABINETS TO VAN

**5.4 Attach Wing Support Brackets to Wing Flare:** Loosely attach **Wing Support Brackets** in the orientation as shown to **Wing Flares** using (1ea) 1/4-20 x 1 Flanged Button Head Screws, Flat Washers and Nylon Locknuts (FIG 70).

**NOTE -** The **Wing Supports** are not directional and need to be installed as shown (FIG 71).




FIG 70




FIG 71

**PARTS NEEDED:** + WING FLARE ASSEMBLY (LAST STEP)

**TOOLS REQUIRED FOR THIS STEP:** + 7/16" WRENCH OR SOCKET

## STEP | 05 FIT CABINETS TO VAN

**5.5 Fit and Install Hinge Side Flare:** Loosely attach the **Hinge Side Cabinet Flare** in the orientation as shown to the **Rear Support** of the **Hinge Side Cabinet** using (2) 1/4-20 x 0.75 **Square Neck Carriage Bolts**, **Flat Washers** and **Nylon Locknuts** (FIG 72). Adjust left, right, up and down until you're satisfied with the fitments and finish by securing all fasteners (FIG 73).




FIG 72




FIG 73

**PARTS NEEDED:** + WING FLARE ASSEMBLY (LAST STEP)

**TOOLS REQUIRED FOR THIS STEP:** + 7/16" WRENCH OR SOCKET

## STEP | 05 FIT CABINETS TO VAN

**5.6 Fit and Install Table Side Flare:** Loosely attach the **Table Side Cabinet Flare** in the orientation as shown to the **Rear Support** of the **Hinge Side Cabinet** using **(2) 1/4-20 x 0.75 Square Neck Carriage Bolts, Flat Washers and Nylon Locknuts (FIG 74)**. Adjust left, right, up and down until you're satisfied with the fitments and finish by securing all fasteners **(FIG 75)**.




FIG 74




FIG 75



**PARTS NEEDED:** + HINGE SIDE CABINET TOP (SP0314B.13)

**TOOLS REQUIRED FOR THIS STEP:** + 3/16" ALLEN WRENCH

## STEP | 05 FIT CABINETS TO VAN

**5.7 Install Hinge Side Cabinet Top:** Attach the **Hinge Side Cabinet Top** to the pre-threaded holes of the **Front and Rear Support** of the **Hinge Side Cabinet** using (10) 1/4-20 x 0.75 **Flanged Button Head Screws** (FIG 76 +77).

**NOTE -** Make sure the cutouts clear hardware.




FIG 76




FIG 77

**PARTS NEEDED:** + BED FRAME (SP0314B.10)  
+ PIVOT BUSHINGS (SP0314B.10)

**TOOLS REQUIRED FOR THIS STEP:**

## STEP | 06 INSTALL BED FRAME

**6.1 Attach Pivot Bushings to Bed Frame:** Insert **Pivot Bushings** into each of the arms of the **Bed Frame** in the orientation shown in FIG 79.




FIG 78




FIG 79

**PARTS NEEDED:** + BED FRAME ASSEMBLY (LAST STEP)

**TOOLS REQUIRED FOR THIS STEP:** + 3/4" WRENCH OR SOCKET

## STEP | 06 INSTALL BED FRAME

**6.2 Install Bed Frame to Hinge Side Cabinet:** Attach the **Bed Frame** to the **Hinge Side Cabinet** using (2) 1/2-13 x 1.75 Hex Head Bolt, Flat Washers and Nylon Locknuts (FIG 81).




FIG 80




FIG 81

## PARTS NEEDED:

TOOLS REQUIRED FOR THIS STEP: + 3/16" ALLEN WRENCH

### STEP | 06 INSTALL BED FRAME

**6.3 Adjust Bed Frame:** Loosen the (2) 1/4-20 x 0.75 Flanged Button Head Screws and the (4) 3/8-16 Square Neck Carriage Bolts in the locations shown in FIG 82 and adjust the **Bed Frame** until it has approximately 1/8"-1/4" of clearance along the **Landing Flange** of the **Table Side Cabinet**. There are **Adjustment Teeth Cutouts** along both sides of the **Bed Frame** to help with alignment (**FIG 83**). Tighten up the screws once you are satisfied with the fitment.




FIG 82




FIG 83



PARTS NEEDED:

TOOLS REQUIRED FOR THIS STEP: + 19MM WRENCH

## STEP | 06 INSTALL BED FRAME

**6.4 Adjust Ball Stud:** Using two 19MM Wrenches, loosen the **Ball Stud** and adjust as needed. Tighten **Jam Nuts** and verify adjustment by closing the door. The **Bed Platform** should click into place easily and release smoothly.

**NOTE** - Do not force the closed. If compression is too tight, damage to the latch could occur.



FIG 84



FIG 85

**PARTS NEEDED:** + BED FRAME GAS STRUTS (SP0314B.10)

**TOOLS REQUIRED FOR THIS STEP:** + 12MM WRENCH  
+ 13MM WRENCH

## STEP | 06 INSTALL BED FRAME

**6.5 Attach Gas Struts to Bed Frame and Strut Brackets:** Lift up the **Bed Frame** and attach the **Gas Struts** to the pre-threaded holes of the **Bed Frame Arms** (FIG 86) and the **Gas Strut Brackets** using (1ea) M8 Cap Nuts (FIG 87).




FIG 86




FIG 87

**PARTS NEEDED:** + WALL MOUNTING BRACKETS (SP0314B.2) (SP0314B.8)

**TOOLS REQUIRED FOR THIS STEP:** + POWER DRILL  
+ 25/64" DRILL BIT  
+ RIVET NUT TOOL  
+ 7/16" WRENCH OR SOCKET  
+ 3/8" WRENCH OR SOCKET

## STEP | 07 INSTALL MURPHY TO VAN

**7.1 Attach Hinge and Table Side Cabinets to Van Walls:** Dry fit the **Mounting Brackets** to the available slots along the **Left and Right Cabinet Ends** for both the **Hinge and Table Side Cabinets** and mark your locations for drilling (**FIG 88**). Drill out your holes with a 25/64" Drill Bit, set your **Rivet Nuts** and secure to the **Cabinet** using (2) 1/4-20 x 0.75 **Square Neck Carriage Bolts**, **Flat Washers** and **Nylon Locknuts**. Secure to set **Rivet Nuts** using 1/4-20 x 1 **Flanged Hex Head Screws** (**FIG 89**).

**NOTE** - If the **Wall Brackets** are able to span the area of a pre-existing mounting surface (such as **L-Track**) you can skip the **Rivet Nuts** and use your preferred mounting method.




FIG 88




FIG 89



**PARTS NEEDED:** + MOUNTING WASHERS (SP0314B.10)  
+ 3/8-16 X 1.75 FLANGED HEX HEAD SCREWS (SP0314B.10)

**TOOLS REQUIRED FOR THIS STEP:** + POWER DRILL  
+ 5/16" DRILL BIT  
+ RUST PREVENTATIVE PAINT  
+ 9/16" WRENCH OR SOCKET

## STEP | 07 INSTALL MURPHY TO VAN

**7.2 Attach Hinge and Table Side Cabinets to Van Floor (optional):** See available mounting slots in the bottom of the **Left and Right Side Cabinet Ends** and **Toe Kick** in FIG 90. If desired, mark your preferred locations for mounting to the floor and drill out using a **5/16" Drill Bit**. Mount using the supplied **3/8-16 x 1.75 Flanged Hex Head Screw, Mounting Washers, 3/8" Oversized Flat Washers and Nylon Locknuts** (FIG 91).

**NOTE -** Take precaution to ensure that where you choose to mount through the floor does not interfere with any factory components or aftermarket accessories already mounted to the bottom of your van. Also, make sure to paint the spots you drill with Rust Preventative Paint.





**PARTS NEEDED:** + COVER PLATES (SP0314B.12)

**TOOLS REQUIRED FOR THIS STEP:** + 3/16" ALLEN WRENCH

## STEP | 08 FINISH MURPHY ASSEMBLY

**8.1 Install Cover Plates:** Attach the **Cover Plates** to the pre-threaded holes of the **Left and Right Cabinet Ends** for both the **Table and Hinge Side Cabinets** using (6ea) 1/4-20 x 0.75 Flanged Button Head Screws (FIG 93).



FIG 92





FIG 93

**PARTS NEEDED:** + END CAP SUPPORT BRACKETS (SP0314B.12)

**TOOLS REQUIRED FOR THIS STEP:** + 3/16" ALLEN WRENCH  
+ 7/16" WRENCH OR SOCKET

## STEP | 08 FINISH MURPHY ASSEMBLY

**8.2 Attach End Cap Supports (Optional):** If desired, there are three additional **Supports** (per side) that can be attached to the **End Caps** that provide extra rigidity to the assembly. Attach using (1ea) 1/4-20 x 0.75 **Flanged Button Head Screws, Flat Washers and Nylon Locknuts**. Attach to the van wall using your preferred method (rivet nuts and screws, self-tapping screws, etc.).



**PARTS NEEDED:** + MOLLE PANEL (SP0314B.17)  
+ PANEL STANDOFF (SP0314B.17)  
+ BINDING BARREL (SP0314B.17)

**TOOLS REQUIRED FOR THIS STEP:** + 3/16" ALLEN WRENCH

## STEP | 08 FINISH MURPHY ASSEMBLY

**8.3 Install Molle Panels (Optional):** If you would like to run Molle Panels, install them to the End Caps at this time using 1/4-20 Binding Barrels and 1/4-20 x 0.5 Flanged Button Head Screws with Panel Standoffs between panels.




FIG 95

**PARTS NEEDED:** + WIRE LOCK PIN (SP0314B.10)

**TOOLS REQUIRED FOR THIS STEP:**

## STEP | 08 FINISH MURPHY ASSEMBLY

**8.4 Stow Mattress and Attach Wire Lock Pin:** If you purchased your **Murphy Bed** with a **Mattress (FIG 96)**, lay it down and stow it away by folding it up (**FIG 97**) and securing the **Bed Frame** to the **Overhead Shelf**. Slide the **Wire Lock Pin (FIG 98)** through the **Bed Frame Arm (FIG 98)** as a final safety measure.



FIG 96



FIG 97



FIG 98

**PARTS NEEDED:** + LARGE SLIDING DOORS (SP0314B.15)  
+ SMALL SLIDING DOORS (SP0314B.15)

**TOOLS REQUIRED FOR THIS STEP:**

## STEP | 08 FINISH MURPHY ASSEMBLY

**8.5 Install Sliding Doors:** Insert **Large Sliding Doors** into **Table Side Cabinet** by sliding the top of the door all the way up in the **Upper Door Track** and then dropping it down into the **Bottom Track** (FIG 99+100). Repeat steps with the other door. For the **Small Sliding Doors**, repeat those steps on the **Hinge Side Cabinet**.




FIG 99



FIG 100



# GET OUT AND EXPLORE!

## + LEAVE US A REVIEW

---

Happy with your new FVC product? We would love to hear (and see) from you! Head to the product page and click "Leave Review." Add a short review and upload a few photos to be showcased on the product page.

## + SHARE YOUR PICS

---

We love seeing how our customers use their FVC products and following along with your adventures. Tag us in your photos with: @flatlinevanco or send them to us via email. We love posting customer pictures in our feed!

## + NEED ANY HELP?

---

If you are having any issues with your product, please reach out, and we will make it right. FVC is a company of van and outdoor enthusiasts that design and use our own products, so we want you to be as stoked on your new parts as we are!



@FLATLINEVANCO