

# HIGH BAR KIT - STANDARD UN1113B



#### TOOLS REQUIRED (NOT INCLUDED)

- + 5/32" ALLEN WRENCH
- + 3/8" SOCKET

### **INSTALL INFO**

TIME TO INSTALL THIS PRODUCT: 30 MINUTES Additional help is suggested for a few of the install steps.

### **BEFORE YOU START**

Please inspect the product and packaging upon delivery to ensure there are no issues and that all parts and hardware are accounted for.


Contact us ASAP if anything is missing at: support@flatlinevanco.com

# **BEFORE YOU START**


All Flatline Van Co products must be properly assembled and secured before attaching to your vehicle. Improper attachment could result in an automobile accident, and could cause serious bodily injury or death to you or to others involved. You are responsible for assembling and securing Flatline Van Co products to your vehicle, checking the mounting points and attachments prior to use, and regularly inspecting the products for wear and or damage. We always recommend you use a professional to install any aftermarket accessories to your vehicle. If you have no mechanical experience and are not thoroughly familiar with the installation procedures, you must have the product installed by a professional installer or other qualified persons. The responsibility is yours and must be taken seriously for everyone's safety.



# **PACKAGE CONTENTS**




# HARDWARE



# INSTALL


Г



#### TOOLS REQUIRED FOR THIS STEP: + 5/32" ALLEN WRENCH

## STEP | 02 HIGH BAR ASSEMBLY

2.1 Attach End Caps to Crossbars: Find the Crossbar End Caps and attach to your Crossbar using (2ea) 1/4-20 x 0.75 Flanged Button Head Hex Drive Screws and Loctite (FIG 3-4).




#### TOOLS REQUIRED FOR THIS STEP: + 5/32" ALLEN WRENCH

## STEP | 02 HIGH BAR ASSEMBLY

2.2 Insert T-Nuts: Slide (2) 1/4-20 T-Nuts into the cutouts of the Crossbar (FIG 5).

**NOTE-** Make sure that the raised edge of the T-Nut goes in first and that the flat edge is in the position to receive hardware.

2.3 Attach Riser to Crossbar: Take the High Bar Riser and position it against the surface of the crossbar. Make sure it is in the orientation as shown in FIG 6 that has the mounting flanges facing inward. Loosely attach using 1/4-20 x 0.5 Flanged Button Head Hex Drive Screws and 1/4 Belleville Lock Washers.



## TOOLS REQUIRED FOR THIS STEP: + 5/32" ALLEN WRENCH

+ 3/8" WRENCH OR SOCKET

## STEP | 03 HIGH BAR INSTALL

**3.1 Install High Bar to Roof Rack:** Slide out High Bar Risers to the appropriate width and use **1/4-20 x 0.75 Flanged Button Head Hex Drive Screws, 1/4 Flat Washers and Nylon Locknuts** to secure **High Bars** to **Roof Rack (FIG 7-8)**.




FIG 8

# GET OUT AND EXPLORE!

#### + LEAVE US A REVIEW

Happy with your new FVC product? We would love to hear (and see) from you! Head to the product page and click "Leave Review." Add a short review and upload a few photos to be showcased on the product page.

#### + SHARE YOUR PICS

We love seeing how our customers use their FVC products and following along with your adventures. Tag us in your photos with: @flatlinevanco or send them to us via email. We love posting customer pictures in our feed!

#### + NEED ANY HELP?

If you are having any issues with your product, please reach out, and we will make it right. FVC is a company of van and outdoor enthusiasts that design and use our own products, so we want you to be as stoked on your new parts as we are!





**@FLATLINEVANCO** 

